



Aluminum Angle Berm Installation

STEP 1: Prepare the berm for setup by unfolding the berm so that it lies flat on the ground with the sides folded in. Pockets for the aluminum angles should be showing. (Fig 1)



STEP 2: Remove the aluminum angles and set them up along side the matching pockets. Aluminum angles will feature a 90° angle. (Fig 2)



STEP 3: Slide the aluminum angles into pockets located on the walls of the berm. This should be done so that the top portion of the angle fits into the pocket, while the bottom sits underneath the berm. This will keep the 90° corner facing the berm wall. (Fig 3)



STEP 4: Once the angles have been installed, walls of the tank can be erected to form a containment wall. (Fig 4)



STEP 5: Pull the sides of the berm out and smooth down the floor of the berm so that it is free from wrinkles. (Fig 5)



Optional Items:

- ◆ Ground Mat
- ◆ Tread Guards
- ◆ Wear Pads
- ◆ Drains (placed on the low point of the berm)



(+1) 772.646.0597



(+1) 772.589.3343



info@geiworks.com

222-2015-11-1